



# **MPSoC Programming In General**

#### Kai Huang



## What is MPSoC?

Multi-Processor System-on-Chip

 Multiple, usually heterogeneous, processing elements, a memory hierarchy, and I/O components, linked by an on-chip interconnect

What is it used for ?

6/3/2013

 Meet the performance needs of domain specific applications while limiting the power consumption


What is MPSoC programming?

 $\odot$  To develop applications for MPSoC platforms



#### What is MPSoC?

#### **Cell Broadband Engine Processor**



IBM

Kai.Huang@tum

#### IBM CELL Broadband Engine

6/3/2013


#### Intel SCC



## Why is MPSoC?

- Moors Law
- Power Wall

 The Power Wall means faster computers get really hot.



transistor

 $10^{10}$ 

 $10^{8}$ 

 $10^{6}$ 

 $10^{4}$ 


count

#### **Power Wall**

2

 Law of Physics: All electrical power consumed is eventually radiated as heat

6/3/2013



Kai.Huang@tum

The Power Wall



Kai.Huang@tum

#### What Is the Problem of MPSoC?

Memory Wall

6/3/2013


- ILP Wall
- Power is still a issue






#### Memory Wall

- The Memory Wall means 1000 pins on a CPU package is way too many
  - Bandwidth limit




## **ILP (Instruction Level Parallelism) Wall**

 ILP Wall means a deeper instruction pipeline really means digging a deeper power hole



#### **Power Wall for MPSoC**



6/3/2013

Kai.Huang@tum



#### What Is the Problem of MPSoC?

Memory Wall

6/3/2013

- ILP Wall
- Power is still a issue

#### How to program an MPSoC affects a lot!

Kai.Huang@tum






### **Parallel Programming Success Stories**

- Scientific/Super computing
  - $\circ$  Where data parallelism is abundant
- Data Centers
  - $\circ$  Independent queries
  - Few shared writes
  - Buying more hardware is cheaper and faster than efficient programming
- Computer Graphics


6/3/2013

- Near infinite, homogeneous parallelism
- Portable libraries: OpenGL, DirectX

#### Language Classification




#### **TIOBE Programming Community Index**





#### **Parallel Architectures in Two Dimensions**



#### What We Need

6/3/2013


- Coarse-grained level parallelism
- Design space exploration
- Easy to adopt Legacy code
- Non-functional prosperity verification

Kai.Huang@tum





#### **Distributed Operation Layer in ETHZ-TIK**






6/3/2013


Kai.Huang@tum

## Versatile MPSoC Software Design Flow



#### 

#### **EU Project SHAPES Tool-Chain**



## **Application Specification**

#### Structure

- Process Network
  - Processes
  - SW channels (FIFO behavior)
- Iterators


 Scalability for processes, SW channels, entire structures

Kai.Huang@tum

#### **Functional specification**

- Language: C/C++
- API: DOL primitives

6/3/2013



Algorithm 1 Process Model	
1: <b>procedure</b> INIT( <b>DOLProcess</b> <i>p</i> )	▷ initialization
2: initialize local data structures	
3: end procedure	
4: <b>procedure</b> FIRE( <b>DOLP</b> rocess <i>p</i> )	▷ execution
5: DOL_read(INPUT, size, buf)	▷ blocking read
6: manipulate	
7: DOL_write(OUTPUT, size, buf)	▷ blocking write
8: end procedure	

#### **Scalability at Specification Level**

- Separation of instruction/thread level parallelism (inside processes) and processlevel parallelism.
- Use of iterators in  $\circ$  architecture specification  $\circ$  application specification  $(i, j) : 1 \le i \le N \land i \le j \le N$

6/3/2013

## **Definition of a process and Example**

```
// Process.h: definition of a process
// local information
typedef struct _local_states *LocalState;
// function pointer
typedef void (* ProcessInit ) (struct _process *);
typedef int (*ProcessFire)(struct _process*);
// place holder
typedef void *WPTR;
typedef struct _process {
   LocalState local;
   ProcessInit init;
   ProcessFire fire;
   WPTR
              wptr;
 Process;
```



### **Definition of a process and Example**

```
// P2.h: header file
   typedef struct _local_states {
                                    int index: int len:
 } P2_State;
#define PORT_IN 1
#define PORT_OUT 2
  // P2.c: C file
   void P2_INIT(Process *p) {
                                   p \rightarrow local \rightarrow index = 0;
                                   p \rightarrow local \rightarrow len = LENGTH;
   }
  int P2_FIRE(Process *p) {
                                     float i:
                                     if (p \rightarrow | ocal \rightarrow | odal \rightarrow | ocal \rightarrow | 
                                                                      READ((void*)PORT_IN, &i, sizeof(float), p);
                                                                     WRITE((void *)PORT_OUT, &i, sizeof(float), p);
                                                                      p—>local —>index++; }
                                      if (p \rightarrow | ocal \rightarrow index >= p \rightarrow | ocal \rightarrow | en)
                                                                     DETACH(p);
                                    return 0;
   }
   // main.c: sample main function
   int main() {
                                    Process p2; P2_State p2_state;
                                    p2.local = p2_state; p2.init = p2_INIT; p2.fire = p2_FIRE;
```

. . . . . . . . . . .


### Scalable MPEG-2 Decoder

```
<!--- N1 is the number of gops processed in parallel --->
<variable name="N1" value="1"/>
<!-- N2 is the number of macroblocks processed in parallel |-</p>
<variable name="N2" value="4" />
<!-- N3 is the number of blocks processed in parallel --->
<variable name="N3" value="2"/>
<!--- instantiate processes --->
<process name="dispatch_gops">
  <iterator variable="i" range="N1">
    <port type="output" name="out" append function="i"/>
 </iterator>
  <source type="c" location="dispatch_gops.c"/>
</process>
<iterator variable="i" range="N1">
  <iterator variable="j" range="N2">
    <process name="dispatch_blocks"></process name="dispatch_blocks">
      <append function="i"/>
      <append function="j"/>
      <iterator variable="k" range="N3">
        <port type="output" name="out"append function="k"/>
```

hnische Hochschule Züri

#### **Scalable MPEG-2 Decoder**


Ì









#### **Target Platform Abstraction (1)**







#### **Target Platform Abstraction (2)**



+ <connection name="memorylink">




























#### **Summary**

- MPSoC programming
  - $\circ$  Reasons
  - Challenges
  - $\circ$  Principles
  - $\circ$  Practices

6/3/2013

Kai.Huang@tum



