function	potential failure (e.g. its state)	effect of failure (e.g. its consequence)		preventive measures	IEC 61508 techniques
			cause		
program storage	Stuck-at for data	program failure	NOR flash fault	self test on start-up and online	signature of one word (8-bit) DC = medium
	Stuck-at for addresses				
	X-talk				